

EN

USERS' MANUAL AND WARNINGS

Introduction

Thank you for purchasing Combo Ski. To ensure safe and proper use of this product, please read this manual and follow all warnings and instructions carefully. Your safety and the safety of others depend on responsible use.

Safety Guidelines

- **Protective Equipment:** Always wear a helmet, gloves, and sturdy footwear. Protective gear is essential to reduce the risk of injury.
- **Recommended Terrain:** Combo Ski is designed for use on snow-covered terrains with a sufficient snow layer. Avoid using on steep slopes, icy surfaces, or in deep powder snow.
- **Child Safety:**
 - Not suitable for children under 3 years old.
 - Children should use Combo Ski under direct adult supervision. The supervising person is responsible for ensuring the child's safety.
- **Obstacle Awareness:** Use the product only in open areas free of obstacles, such as rocks, trees, or other hazards. Be mindful of other people around you.

Usage Instructions

- **Preparation:**
 - Ensure all parts of the product are clean and undamaged before each use.
 - Verify that your footwear is compatible with the binding system of Combo Ski.
- **Attachment:** Follow the provided instructions to properly secure Combo Ski to your footwear. Check the bindings to ensure they are firmly fastened.
- **Mode Switching:** Use the integrated mechanism to switch between walking and sliding modes as required. Refer to the manual for specific steps.

Warnings

- Do not use the product if it is damaged or shows signs of wear that may compromise its functionality.
- Avoid exposing the product to temperatures above 40 °C or below -20 °C, as extreme conditions can lead to material damage.
- Keep the product packaging out of reach of children to prevent suffocation risks.

Liability and Risk

Using Combo Ski involves inherent risks. By using this product, you accept full responsibility for:

- Learning how to use Combo Ski safely.
- Any injuries, damages, or accidents resulting from its use.

Combo Ski s.r.o. is not liable for any injuries or damages caused by improper or unsafe use of the product. Users must exercise sound judgment, caution, and responsibility during all activities involving Combo Ski.

Care and Maintenance

- Store Combo Ski in a dry place away from direct sunlight or extreme temperatures.
- Clean all components after use to ensure optimal performance and longevity.

Contact Information

For additional support or replacement parts, please visit our website at www.comboski.cz or contact customer service.

Disclaimer: Your safety is your responsibility. Please follow these instructions and prioritize your health and the safety of others during use.

CZ

UŽIVATELSKÁ PŘÍRUČKA A VAROVÁNÍ

Úvod

Děkujeme, že jste si zakoupili Combo Ski. Abyste zajistili bezpečné a správné používání tohoto produktu, přečtěte si prosím tento návod a důsledně dodržujte všechny varování a pokyny. Vaše bezpečnost a bezpečnost ostatních závisí na zodpovědném používání.

Bezpečnostní pokyny

- **Ochranné vybavení:** Vždy používejte helmu, rukavice a pevnou obuv. Ochranné pomůcky jsou nezbytné ke snížení rizika zranění.
- **Doporučený terén:** Combo Ski je určený pro použití na zasněžených terénech s dostatečnou vrstvou sněhu. Vyhněte se použití na strmých svazích, zledovatělých površích nebo v hlubokém prašanu.
- **Bezpečnost dětí:**
 - **Nejvhodnější věk:** Není vhodné pro děti mladší 3 let.
 - **Děti by měly Combo Ski používat pouze pod přímým dohledem dospělé osoby. Zodpovědnost za bezpečnost dítěte nese dohlížející osoba.**
- **Pozor na překážky:** Používejte produkt pouze v otevřených oblastech bez překážek, jako jsou kameny, stromy nebo jiné nebezpečné prvky. Dbejte na přítomnost dalších osob ve vašem okolí.

Pokyny k použití

- **Příprava:**
 - Před každým použitím zkontrolujte, zda jsou všechny části produktu čisté a nepoškozené.
 - Ujistěte se, že vaše obuv je kompatibilní se systémem vázání Combo Ski.
- **Přípevnění:** Postupujte podle přiloženého návodu k zajištění správného připevnění Combo Ski k vaší obuvi. Ujistěte se, že vázání je pevně uchyceno.
- **Přepínání režimů:** Použijte integrovaný mechanismus k přepínání mezi režimem chůze a klouzání podle potřeby. Podrobné kroky najdete v návodu.

Varování

- Nepoužívejte produkt, pokud je poškozený nebo vykazuje známky opotřebení, které by mohly ovlivnit jeho funkčnost.
- Nevystavujte produkt teplotám vyšším než 40 °C nebo nižším než -20 °C, protože extrémní podmínky mohou způsobit poškození materiálu.
- Obalový materiál uchovávejte mimo dosah dětí, aby se zabránilo riziku udušení.

Odpovědnost a riziko

Používání Combo Ski je spojeno s určitými riziky. Používáním tohoto produktu přijímáte plnou odpovědnost za:

- Naučení se bezpečnému používání Combo Ski.
- Jakákoli zranění, škody nebo nehody způsobené jeho použitím.

Společnost Combo Ski s.r.o. nenes odpovědnost za zranění nebo škody způsobené nesprávným či nebezpečným používáním produktu. Uživatelé musí při všech aktivitách spojených s Combo Ski postupovat opatrně, s rozvahou a odpovědně.

Údržba a péče

- Uchovávejte Combo Ski na suchém místě, mimo přímé sluneční záření nebo extrémní teploty.
- Po použití očistěte všechny části produktu, abyste zajistili jeho optimální výkon a dlouhou životnost.

Kontaktní informace

Pro další podporu nebo náhradní díly navštivte naše webové stránky na www.comboski.cz nebo kontaktujte zákaznickou podporu.

Vyloučení odpovědnosti: Vaše bezpečnost je vaší odpovědností. Dodržujte tyto pokyny a při používání produktu upřednostňujte své zdraví a bezpečnost ostatních.